

Underpinner Spares

Tip Sheet: How to set the Morso measuring scales

Example is based on a 60mm wide moulding being set to measure 30cm (300mm) inside length

